
# REPLACEMENT COMPONENTS



No Holes Base 425-5697



Hex Key 425-3379



Articulated Swing Arm 425-1188

(2) Hex Head Cap Screws & (2) Lock Washers 425-3385

### Ratchet Handle 425-1273

# JOTTO DESK ACCESSORIES

Specifications subject to change without notice



#### **PIVOTING CELL PHONE HOLDER**

Model 425-5299

Allows you to tilt your phone independent of the desktop angle. Mounts to side of 10" x 12" Desktop.



#### **SCREEN SUPPORT - A-MOD**

#### Model 450-0449

The Screen Support is designed to keep your screen in place while you use your computer. It attaches directly to the A-MOD Desktop and adjusts in height and tilt angle.



USB LIGHT

12" flexible wand with blue LED's and rheostat to adjust brightness. Three foot power cord plugs into cigarette



#### **KENSINGTON® MASTERLOCK®**

Model 425-1317 Computer securing system uses Kensington locking system. Fasten security cable to permanent structure in vehicle.



**SCREEN SUPPORT - ACD** 

#### Model 425-5999

The Screen Support is designed to keep your screen in place while you use your computer. It attaches directly to the ACD Desktop and adjusts in height and tilt angle.



WARNING: Do not install or use this product in any manner which would interfere with any of the vehicles controls, air bags or safety devices. Follow vehicle owner's manual instructions should a dash warning light come on after installation of this desk. Do not install or use this product in any manner which causes a safety hazard for vehicle and/or occupants.

425-5698

To avoid serious injury do not place this desk or any objects between the air bags and yourself or any passengers. If necessary remove the desk before driving. Store in trunk or other safe place.

We recommend that you do not work on the Jotto Desk while driving! Park safely, then use. Remember, driving safely comes first.

WARNING: Make sure of and check on a regular basis that all knobs, fastening devices and handles are tight and secure. Repair or replace any faulty or worn parts. All equipment, such as computers, printers, phones, etc. must be safely secured when vehicle is in motion.

DISCLAIMER: The manufacturer of this product may not be held liable for any accidents, injuries or problems caused by the use or installation of this product.

Specifications subject to change without notice.

√
jottodesk.com
 toll free 1.877.455.6886



209 W. EASY ST., ROGERS, AR 72756 • www.EVERYTHINGBUTLIGHTS.com • 1/19 Jotto Desk® is a patented product and Registered Trademark of Assembled Products<sup>™</sup> Corporation. Specifications subject to change without notice.

BRACE KIT

Model 425-5238

The Brace Kit attaches to the stand

providing additional support. It can


be adjusted in length and mounts to

flat, vertical or angled surfaces.



### **INSTALLATION PROCEDURE** READ INSTRUCTIONS BEFORE BEGINNING INSTALLATION





### STAND ASSEMBLY OPERATION

- 1. Remove Hex Head Cap Screws from stand assembly and place tube over the No-Holes Mount Base.
- 2. Thread (2) Hex Head Cap Screws with (2) Lock Washers through tube and into front and rear of No Holes Mount post at bottom of tube. (A)
- Raise inner rod to desired height. Thread (2) Hex Head Cap Screws with (2) Lock Washers into front and rear holes at top of tube. (B)
- 4. Use provided Hex Key to tighten (4) Hex Head Cap Screws to ensure secure positioning.

- 1. Loosen both of the rear seat bolts as much as possible without removing them from the mounting holes. This will allow enough play in the seat without allowing the seat to become misaligned on the rear holes.
- 2. Completely remove both of the front seat bolts.
- 3. Slide the NHM base under the front seat mounts and get the bolts started.
- 4. After both of the front seat bolts are started, make sure the NHM base is positioned as close to the floor as the mounting slots will allow.
- 5. Completely tighten both of the front seat bolts back down.
- 6. Replace any trim that was removed to complete the install of the NHM Base.
- 7. Remove the two front passenger seat bolts. (Side panel will have to be removed to properly access outer bolt. Once base is installed, side panel should be set aside and not used.)
- 8. Line up mounting base, insert original bolts and tighten.
- 9. Assemble the desktop stand to the mount base, starting with the vertical tube. Use (2) hex head cap screws and (2) lock washers to secure verticaltube to mount post.
- 10. Place articulated swing arm over the 5/8" end of the telescoping rod. Tighten with ratchet handle.
- 11. Attach desktop to end of articulated swing arm and secure by tightening ratchet handle.

## RATCHET CLAMP OPERATION

NOTE: Insert the ra unthreaded arm and tigh side first will properly To adjust, pu counter cloc en. If neede for adjustme NOTE: Ratchet har.

**NOTE:** Insert the ratchet handle through the unthreaded side of the articulated swing arm and tighten. Going through threaded side first will not allow the arm to tighten properly

To adjust, pull handle out (B) and rotate counter clockwise (A), release and tighten. If needed, use 1/8" hex head wrench for adjustment (C)

Ratchet handles are spring loaded and can be readjusted to tighten.